



QUICK START · CEECOACH PLUS

# CEEEOACH PLUS

Wireless instruction system — pre-paired by Horse Watch and ready to use.


## 1 · SWITCHING ON AND OFF

- 1 Make sure the CEECOACH Plus is **charged** (USB-C cable in the box).
- 2 Press and hold the **centre key** (on/off, number 6) for at least **3 seconds**.
- 3 The light ring lights up briefly (green, yellow or red depending on the battery) and you hear *"Power on"*. The unit is on.
- 4 **Switching off:** press and hold the same key again for at least 3 seconds. You hear *"Power off"*.

### Good to know

Your CEECOACH Plus units have been **paired with each other by us** in advance. You do not need to set up a group or connection yourself: switching on is enough.

## THE KEYS AT A GLANCE



- |                                                                          |                                                  |
|--------------------------------------------------------------------------|--------------------------------------------------|
| 1 <b>Function key</b><br>pairing with other units                        | 2 <b>Headset socket</b><br>for the wired headset |
| 3 <b>USB-C socket</b><br>charging                                        | 4 <b>Minus key</b><br>volume down                |
| 5 <b>Function key</b><br>pairing with other units or a Bluetooth headset | 6 <b>Main key</b><br>on/off · microphone on/off  |
| 7 <b>Plus key</b><br>volume up                                           | 8 <b>Light ring</b><br>shows the status          |

## 2 · OPERATION

### On/off key (6)

The large round key in the middle. Use it to switch the CEECOACH Plus on and off.

### Volume

Plus key (7) = louder, minus key (4) = quieter.

### Light ring

Turns **green** when the unit is ready for use.

### Key lock


If the light ring turns **violet (purple)**, the key lock is on. This prevents keys from being pressed by accident. Press the large round key (6) **3 times** to switch the lock off or on again.

### In the box

- CEECOACH Plus (2× in a duo set)
- Belt clip
- USB-C cable
- Wired headset
- Strap for your arm or the reins

## WHAT THE LIGHT RING MEANS

- **Green** — battery above 70 % · connected, at least one other unit in range
- **Yellow** — battery between 30 % and 70 %
- **Red** — battery almost empty (below 30 %) — charge
- **White** — no connection to other units
- **Cyan** — connected, but no other unit in range
- **Blue** — can now be connected to a Bluetooth headset
- **Magenta** — microphone is off
- **Violet** — key lock is on



### More help & software

Scan the code for the full manuals (NL / EN / DE) and the latest CEECOACH software.

[manuals.horse-watch.nl/ceecoach.html](https://manuals.horse-watch.nl/ceecoach.html)

● QUESTIONS? MESSAGE US

**+31 (0)418 51 60 28**

Call the same number or email [info@horse-watch.nl](mailto:info@horse-watch.nl) · [www.horse-watch.nl](http://www.horse-watch.nl)