



CEE COACH PLUS · EN


CONNECT A BLUETOOTH HEADSET

Prefer wireless earphones or your own headset? Here's how to connect them.

You can use the CeeCoach Plus with the **wired headset** from the box, or with a **Bluetooth headset or earphones**. Once connected, the unit remembers the headset: next time they connect by themselves as soon as you switch the unit on.

- 1 Switch the unit on** (main button 3 seconds) and wait until the ring flashes.
Key lock on (four flashing LEDs)? Plus and minus together for 3 seconds turns it off.
- 2 Switch the headset on and put it in pairing mode.** The headset's manual explains how; usually a blue light then flashes.
- 3 Briefly press the side function button** on the unit (the flat button). The light ring rotates **blue**: the unit is searching for the headset.
- 4 Wait until the rotating stops.** You're connected; from now on you hear the others through the headset.
- 5 Quick test.** Ask someone to say something and set the volume with plus and minus.

STEP 3 · SIDE FUNCTION BUTTON



Briefly press the flat side button (2); the ring (1) rotates blue.

GOOD TO KNOW

Different headset? Switch the current one off and pair the new one as above.

Wired and Bluetooth? Plug in the wired headset and it takes priority. Unplug it: sound goes back to Bluetooth.

Same side. Wear unit and headset on the same side of your body; less interference.

Open-ear earphones let the surroundings through; volume can often be lower.

Matching earphones and headsets

Horse Watch earphones and headsets that work well with the CeeCoach Plus are on horse-watch.nl under Instructor sets.

Can't connect?

Check that the headset is really in pairing mode and its battery is full. Some headsets allow only one connection: disconnect it from your phone first. Then try again from step 1.

● MESSAGE US

+31 (0)418 51 60 28

Call the same number
info@horse-watch.nl · www.horse-watch.nl



Full manual
All functions of the
CeeCoach Plus