

NEED HELP?

● WHATSAPP US

+31 (0)418 51 60 28

Prefer to call or email?

Call the same number or email info@horse-watch.nl
www.horse-watch.nl



Online help

Solutions to the most common problems



Full manual — worth scanning

Settings that make daily use much easier: Vibration mode, work duration, image, lines off.

TIPS & TRICKS

SOLVING PROBLEMS

1 No image in the app?

Check that your phone is still on the **backcam** network; it sometimes jumps back to your own wifi. If asked "no internet, connect anyway?", choose **yes**.

2 Image stutters or drops out?

Point the antenna upright and keep as little metal as possible between camera and phone.

3 Camera will not turn on or switches off?

Charge via USB-C with a standard 5V charger. If the green light next to the blue one flashes, the battery is almost empty.

4 App cannot find the camera (Android)?

Allow the app access to **location** and the **floating window**, otherwise it is not allowed to see the camera network.

5 Lines on the image?

Parking lines from the app. Turn off: Settings > Calibration > Marking switch.

While you watch, your phone is connected to the camera wifi. **Mobile data keeps working**, so navigation and music do too. Afterwards your phone reconnects to your own wifi by itself.

STILL STUCK?

Do not change any settings and do not reset the camera. Call or WhatsApp us on +31 (0)418 51 60 28.



MANUAL · EN

HORSE WATCH TRAVEL 2.0

One camera, battery built in. Ready in three steps.

AN EYE ON YOUR HORSE

01

STEP 1

DOWNLOAD THE APP



Scan to download

Works on iPhone and Android — the page picks the right version for you

- 1 Scan the QR code and install the app.
- 2 Open the app once and allow access to **location** and, on Android, the **floating window**. This lets the app find the camera.
- 3 You do **not** need an account and you do not need to log in.

Charge fully first

Before first use, charge the camera fully via USB-C with a **standard 5V charger** (no fast charger). Full = four green lights. 5200 mAh battery: up to about 20 hours of viewing, less with night vision.

02

STEP 2

CAMERA ON & CONNECT

- 1 Screw the **antenna** onto the camera and point it upright.
- 2 Touch and hold the **power button for 3 seconds** (with your finger, no glove). The blue light comes on: the camera is transmitting.
- 3 Go to **Settings > Wifi** and choose the network starting with **backcam**. Password **1234567890**. Does your phone say "no internet"? Choose **connect anyway**.
- 4 Open the app. The first time, tap **Add Device**; after that the image appears by itself.

- **4 green lights** = battery. Press the button briefly = see the level.
- **Light next to the blue one flashes** = almost empty, charge.
- **Blue** = camera is on and transmitting wifi.

FRONT



03

STEP 3

MOUNT THE CAMERA

- 1 Choose a spot **high in the trailer or lorry**, with a clear view of your horse. Viewing angle 100°.
- 2 **Steel wall?** The magnetic back clicks straight onto it.
- 3 **Plastic or aluminium?** Clean and dry the surface, stick on the **supplied metal plate** and press for 30 sec. Click the camera onto it.
- 4 Unloaded? Switch the camera **off** (button 3 sec.), or the battery will drain. Or set Vibration mode once (below). More useful settings: QR on the back.

Set Vibration mode (our advice)

Sleeps by itself, wakes as soon as the trailer moves.

1. Camera on, tap the button **3× quickly**. Keep tapping until the green light next to the blue one flashes; hold the button 2 sec.
2. Tap the button **5× quickly**. Keep tapping until **3 green lights** flash (5 min); hold the button 2 sec.

Range

Up to 100 m in open space; metal in between cuts that a lot. Point the antenna towards the cab.